

<BBS>

B(ye) PBBS WILL DISCONNECT
J(heard) CALLSIGNS WITH DAYSTAMP
J S(hort) HEARD CALLSIGNS ONLY
J L(ong) CALLSIGNS WITH DAYSTAMP AND VIAS
L [x [y]] [;] LIST MESSAGES x THRU y YOU CAN READ
L <|> call LIST MESSAGES FROM OR TO CALL
LB LIST BULLETINS
LC [cat] LIST CATEGORIES
LL n LIST LAST n MESSAGES
LM(ine) LIST UNREAD MESSAGES ADDRESSED TO YOU
LO [+|-] LISTING ORDER
LT LIST TRAFFIC
K(ill) n DELETE MESSAGE NUMBER n
KM(ine) DELETE ALL READ MESSAGES ADDRESSED TO YOU
R(ead) n DISPLAY MESSAGE NUMBER n
RH n DISPLAY MESSAGE n WITH HEADERS
RM(ine) READ ALL MESSAGES ADDRESSED TO YOU
S(end) call SEND MESSAGE TO callsign
S[B|P|T] call SEND BULLETIN, PRIVATE, or TRAFFIC

<NODES>

ABORT STOP A CONNECTION IN PROGRESS
B(ye) NODE WILL DISCONNECT
C(onnect) call CONNECT TO callsign
C call S(tay) STAY CONNECTED TO NODE WHEN END DISCONNECTS
J(heard) CALLSIGNS WITH DAYSTAMP
J S(hort) HEARD CALLSIGNS ONLY
J L(ong) CALLSIGNS WITH DAYSTAMP AND VIAS
N(odes) HEARD NODE CALLSIGNS WITH DAYSTAMP
N S(hort) NODE CALLSIGNS ONLY
N L(ong) NODE CALLSIGNS WITH DAYSTAMP AND VIAS

<Winpack PMS>

B(ye) PBBS Will Disconnect
I(nfo) Information About this pbbs
L [x [y]] List Messages x thru y you can read
L < call List Messages from or to call
LL n List Last n messages
LM(ine) List Unread messages addressed to you
K(ill) n Delete Message number n
KM(ine) Delete All read messages addressed to you
R(ead) n Read Message number n
RM(ine) Read All messages addressed to you
S(end) call Send Message to callsign
S[B] call Send Bulletin, or personal